





Part List

Part No	Description	Quant.	Part No	Description	Quant.
1	Plunger Piston	1	42	Spring	1
2	Dust Seal Ø18 - Ø26 - 4/6	1	43	Ball housing	1
3	O-ring Ø17.8 x 2.4	1	44	Steel Ball Ø5	1
4	Back-up ring Ø18 x Ø22 x 1.25	1	45	Handle BTN - 2500	1
5	E-ring Ø20	1	46	Handle Axis	1
6	Spring Cap	1	47	Spring Pin Ø3 x 25	1
7	Spring	1	48	Roller Pin	1
8	Steel Ball Ø14	1	49	Roller	1
9	Ram Piston	1	50	Bushing	2
10	Dust Seal Ø32 - Ø40 - 5/6.5	1	51	Lever	1
11	O-ring Ø30.8 x 3.6	2	52	Plastic Roller	1
12	Back-up ring Ø32 x Ø38 x 1.5	1	53	Spring Plate	1
13	Oil Plug	1	54	Spring Pin Ø4 x 16	1
14	O-ring Ø6 x 1.8	1	55	Spring Pin Ø4 x 16	1
15	Pump Body BM - N32	1	56	Spring Pin Ø4 x 30	2
16	Spring Pin Ø8 x 25	1	57	Spring Pin Ø6 x 30	1
17	Cam	1	58	Anchor Bolt	1
18	Bearing Base	1	59	Nut M6	1
19	Bearing 51109	1	60	Chain	1
20	Table	1	61	Release Rod	1
21	Steering Wheel Axis	1	62	Fork	1
22	Spring Pin Ø6 x 35	2	63	Lifting Yoke	1
23	Spring Pin Ø5 x 30	8	64	Plastic Bushing 20 x 27 x 30	2
24	Spring Pin Ø8 x 45	1	66	E-ring Ø20	2
25	Snap Ring Ø45	1	67	Lifting Yoke Axis 540	1
26	Steering Wheel Ø180 x 50	2	68	Rod 1150	2
27	Bearing 6204	12	69	Arm	2
28	Snap ring Ø20	2	70	Steel Plate	4
29	Release Nozzle	1	71	Load Wheel	4
30	O-ring Ø4 x 2	2	72	Load Wheel Axis	4
31	Spring	1	73	Arm Pin	2
32	Release Plug	1	74	Rod Pin	2
33	Copper Washer Ø14.5 x Ø22 x 1.5	1	75	Washer	4
34	Spring	1	76	Spring Pin Ø5 x 40	2
35	Spring	1	77	Grease Nipple	1
36	Steel Ball Ø6	2	78	Rubber	1
37	Valve Housing	1	79	Screw M6 x 10	1
38	Steel Ball Ø9	1	80	Bushing 22 x 20 x 14 x 1	2
39	Relief Screw	1	81	Bushing 18 x 16 x 16	4
40	O-ring Ø11.2 x 2.65	1	83	inner Circlip Ø25	2
41	Relief Screw	1	86	Wheel cap	2







HYDRAULIC CIRCUIT

